Watch winder USER MANUAL


Please read the instructions about your new watch winder before use.


4. Additional extra functions(Alternative): LED light characteristic:

The LED Light will bright when you turn on the little power switch on the back of the box, and the light will be off when you turn off the switch. In generally, the blue light is under normal work, when the battery is lower volume, the light is red, pls change it at once to keep it normal working. LED light is under the board.

5. CAUTION:

- 1) Please use the adaptor included with your watch winder or similar adaptor with exact same voltage output
- 2) Please do not manually spin the winder. This will damage your watch winder and void your warranty.
- 3) avoid exposing the watch winder to direct sun, water or other moisture, and extreme temperatures which may damage the box





Setting Program Information

