4. Additional extra functions(Alternative):
LED light characteristic:

The LED Light will bright when you turn on the little power switch on the back of the box, and the light will be off when you turn off the switch. In generally, the blue light is under normal work, when the battery is lower volume, the light is red, pls change it at once to keep it normal working. LED light is under the board.

5. CAUTION:

1.To operate:

2pcs Batteries

- 1) Please use the adaptor included with your watch winder or similar adaptor with exact same voltage output
- 2) Please do not manually spin the winder. This will damage your watch winder and void your
- avoid exposing the watch winder to direct sun, water or other moisture, and extreme temperatures which may damage the box

Watch winder USER MANUAL

Please read the instructions about your new watch winder before use

3. Different watch pillows Setting Program Information Switch and plug diagram behind your watch winder 1) Handmade Velvet/Leather Pillow The watch pillow(s) that are included with the watch winder also STOP/Off The unit is off. include a belt which assists in holding watches with a longer bracelet length Switch for LED ligh On this setting, the winder will turn clockwise pillow with belt only, turning 1 minute and resting for 20 minutes, then repeating cycle. 2pcs 1.5V battery to the snaps.Replace the cover On this setting, the winder will turn counterockwise only, turning 3 minutes and resting for 50 minutes, then repeating cycle. On this setting, the winder will turn counterclockwise for 2 minutes and rest for 28 minutes 2) Black Soft Pillow then will turn clockwise for 2 minutes and rest for 28 minutes, then repeats complete cycle eplace back The new cusion is flexible enough to hold with both the big or small watches. What is more, it will allow the box size to be smaller than normal On this setting, the winder will turn clockwise for 10 minutes. This cycle will repeat for 1 PROGRAM 2 PROGRAM 3 hour then will rest for 7 hours. The cycle will PROGRAM 1 PROGRAM 4 restart from the beginning after every cycle STOP CFF+

you turn off the switch. In generally, the blue light is under normal work, when the battery is lower volume, the light is red, pls change it at once to keep it normal working. LED light is under the board. 5. CAUTION:

Setting Program Information

On this setting, the winder will turn clockwise

On this setting, the winder will turn counter-

On this setting, the winder will turn counter-

then will turn clockwise for 3 minutes and rest

for 28 minutes, then repeats complete cycle

On this setting, the winder will turn clockwise

for 10 minutes then turn counter-clockwise

hour then will rest for 4 hours. The cycle will

restart from the beginning after every cycle.

clockwise only, turning 3 minutes and resting

only, turning 3 minute and resting for 28

minutes, then repeating cycle.

for 28 minutes, then repeating cycle

STOP/Off

1) Please use the adaptor included with your watch winder or similar adaptor with exact same voltage output

4. Additional extra functions(Alternative):

The LED Light will bright when you turn on the little power

switch on the back of the box, and the light will be off when

LED light characteristic:

2pcs 1.5V battery to the snaps.Replace the cover

STOP CFF+

replace back

PROGRAM 2 → PROGRAM 3

PROGRAM 1 PROGRAM 4

- 2) Please do not manually spin the winder. This will damage your watch winder and void your
- avoid exposing the watch winder to direct sun, water or other moisture, and extreme temperatures which may damage the box

Watch winder

Please read the instructions about your new watch winder before use

The watch pillow(s) that are included with the watch winder also

The new cusion is flexible enough to hold with both the big or

small watches. What is more, it will allow the box size

pillow without belt

assists in holding watches with a longer bracelet length.

USER MANUAL

3. Different watch pillows

include a belt which

2) Black Soft Pillow

to be smaller than normal

1) Handmade Velvet/Leather Pillow

Additional extra functions(Alternative): LED light characteristic:


The LED Light will bright when you turn on the little power switch on the back of the box, and the light will be off when you turn off the switch. In generally, the blue light is under normal work, when the battery is lower volume, the light is red, pls change it at once to keep it normal working. LED light is under the board.

5. CAUTION:

- 1) Please use the adaptor included with your watch winder or similar adaptor with exact same voltage output
- 2) Please do not manually spin the winder. This will damage your watch winder and void your
- 3) avoid exposing the watch winder to direct sun, water or other moisture, and extreme temperatures which may damage the box

Watch winder USER MANUAL

Please read the instructions about your new watch winder before use



Setting Program Information The unit is off. On this setting, the winder will turn clockwis only, turning 3 minute and resting for 40 minutes, then repeating cycle. On this setting, the winder will turn counterclockwise only, turning 3 minutes and restin for 40 minutes, then repeating cycle. On this setting, the winder will turn counterclockwise for 2 minutes and rest for 28 minutes then will turn clockwise for 2 minutes and res for 28 minutes, then repeats complete cycle On this setting, the winder will turn clockwis for 10 minutes then turn counter-clockwise for 10 minutes. This cycle will repeat for 1

hour then will rest for 7 hours. The cycle will


restart from the beginning after every cycle.

3. Different watch pillows 1) Handmade Velvet/Leather Pillow The watch pillow(s) that are included with the watch winder also include a belt which assists in holding watches with a longer bracelet length. 2) Black Soft Pillow The new cusion is flexible enough to hold with both the big or small watches. What is more, it will allow the box size to be smaller than normal


.To operate:



Watch winder



1. Switch and plug diagram behind your watch winder



cycling for 4 minutes, then (4) stops 52 minutes.(5) and repeats above mentioned (steps 1 to 4 indications) spinning cycling

unit, and attach 2pcs 1.5V battery to the snaps. Replace









or similar adaptor with exact same voltage output

2) Please do not manually spin the winder. This will damage your watch winder and void your warrant 3) avoid exposing the watch winder to direct sun, water o other moisture, and extreme temperatures which may damage the box